

Sharp GX10 Guide



WAP over GPRS Setup

- Press the **M** key to enter the menu system.
- Press the **up arrow** key three times to highlight **Settings** and press the **M** key.
- Press the **down arrow** key three times to highlight **Internet Settings** and press the **M** key.
- Press the **M** key to select **WAP Settings**.
- Using the **down arrow** key highlight the next available profile and press the **M** key.
- Press the **M** key to select **Profile Name**.
- Using the phone's keypad enter **Vodafone GPRS** and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

To enter lower/upper case characters, press and hold the star '' key.*

Helpful Tip:

To enter a space ' ' character, press the zero '0' key.

- Press the **down arrow** key to highlight **IP Address** and press the **M** key.
- Using the phone's keypad enter **172.030.038.003** and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

To enter a full stop '.' character, press the hash '#' key.

- Press the **down arrow** key to highlight **Homepage** and press the **M** key.
- Using the phone's keypad enter **http://wap.vodafone.co.nz** (case sensitive) and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

*To enter a colon ':' character, press the '#' key then using the **arrow** keys highlight the colon ':' and press the **M** key.*

Helpful Tip:

*To enter a forward slash '/' character, press the '#' key then using the **arrow** keys highlight the forward slash '/' and press the **M** key.*

- Press the **down arrow** key to highlight **Port Number** and press the **M** key.
- Change the **Port Number** to **09201** and press the **M** key.
- Press the **down arrow** key three times to highlight **Connection Type** and press the **M** key.
- Press the **down arrow** key to highlight **GPRS** and press the **M** key.
- Press the **down arrow** key to highlight **GPRS Settings** and press the **M** key.
- Press the **M** key to select **APN**.

- Using the phone's keypad enter **live.vodafone.com** and press the **M** key. Use the **right selection** key to delete any unwanted characters.
- Press the **right selection** key to return to the **WAP Profile** menu.
- Press the **down arrow** key to highlight **CSD Settings** and press the **M** key.
- Press the **M** key to select **Phone No.**
- Using the phone's keypad enter **+6421700747** and press the **M** key. Use the **right selection** key to delete any unwanted characters.
- Press the **down arrow** key twice to highlight **UserName** and press the **M** key.
- Using the phone's keypad enter **voda** (case sensitive) and press the **M** key. Use the **right selection** key to delete any unwanted characters.
- Press the **down arrow** key to highlight **Password** and press the **M** key.
- Using the phone's keypad enter **user** (case sensitive) and press the **M** key. Use the **right selection** key to delete any unwanted characters.
- Press the **right selection** key to return to the **WAP Profile** menu.
- Press the **down arrow** key twice to highlight **Setup End** and press the **M** key.
- Press the **M** key twice to activate the newly defined profile.

WAP over GPRS Data

- Press the **M** key to enter the menu system.
 - Press the **up arrow** key three times to highlight **Settings** and press the **M** key.
- Press the **down arrow** key three times to highlight **Internet Settings** and press the **M** key.
 - Press the **M** key to select **WAP Settings**.
 - Using the **down arrow** key highlight the next available profile and press the **M** key.
 - Press the **M** key to select **Profile Name**.
 - Using the phone's keypad enter **Vodafone** and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

To enter lower/upper case characters, press and hold the star '' key.*

Helpful Tip:

To enter a space ' ' character, press the zero '0' key.

- Press the **down arrow** key to highlight **IP Address** and press the **M** key.
- Using the phone's keypad enter **172.030.038.003** and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

To enter a full stop '.' character, press the hash '#' key.

- Press the **down arrow** key to highlight **Homepage** and press the **M** key.

- Using the phone's keypad enter **http://wap.vodafone.co.nz** (case sensitive) and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

*To enter a colon ':' character, press the '#' key then using the **arrow** keys highlight the colon ':' and press the **M** key.*

Helpful Tip:

*To enter a forward slash '/' character, press the '#' key then using the **arrow** keys highlight the forward slash '/' and press the **M** key.*

- Press the **down arrow** key three time to highlight **Connection Type** and press the **M** key.
- Press the **down arrow** key twice to highlight **CSD** and press the **M** key.
- Press the **down arrow** key twice to highlight **CSD Settings** and press the **M** key.
- Press the **M** key to select **Phone No.**
- Using the phone's keypad enter **+6421700747** and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

For a plus '+' character press the star '' key twice.*

- Press the **down arrow** key twice to highlight **UserName** and press the **M** key.
- Using the phone's keypad enter **voda** (case sensitive) and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

*To enter an at '@' character, press the '#' key then using the **arrow** keys highlight the at '@' character and press the **M** key.*

- Press the **down arrow** key to highlight **Password** and press the **M** key.
- Using the phone's keypad enter **user** (case sensitive) and press the **M** key. Use the **right selection** key to delete any unwanted characters.
- Press the **right selection** key to return to the **WAP Profile** menu.
- Press the **down arrow** key to highlight **Setup End** and press the **M** key.
- Press the **M** key twice to activate the newly defined profile.

MMS Setup

- Press the **M** key to enter the menu system.
- Press the **up arrow** key three times to highlight **Settings** and press the **M** key.
- Press the **down arrow** key three times to highlight **Internet Settings** and press the **M** key.
- Press the **M** key to select **MMS Settings**.
- Using the **down arrow** key highlight the next available profile and press the **M** key.
- Press the **M** key to select **Profile Name**.
- Using the phone's keypad enter **PXT MMS** and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

To enter lower/upper case characters, press and hold the star '' key*

- Press the **down arrow** key to highlight **IP Address** and press the **M** key.
- Using the phone's keypad enter **172.030.038.003** and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

To enter a full stop '.' character, press the hash '#' key

- Press the **down arrow** key to highlight **Relay Server URL** and press the **M** key.
- Using the phone's keypad enter **http://pxt.vodafone.net.nz/pxtsend** (case sensitive) and press the **M** key. Use the **right selection** key to delete any unwanted characters.

Helpful Tip:

*To enter a colon ':' character, press the '#' key then using the **arrow** keys highlight the colon ':' and press the **M** key*

Helpful Tip:

*To enter a forward slash '/' character, press the '#' key then using the **arrow** keys highlight the forward slash '/' and press the **M** key*

- Press the **down arrow** key to highlight **Port Number** and press the **M** key.
- Change the **Port Number** to **09201** and press the **M** key.
- Press the **down arrow** key to highlight **Connection Type** and press the **M** key.
- Press the **down arrow** key to highlight **GPRS** and press the **M** key.
- Press the **down arrow** key to highlight **GPRS Settings** and press the **M** key.
- Press the **M** key to select **APN**.
- Using the phone's keypad enter **live.vodafone.com** and press the **M** key. Use the **right selection** key to delete any unwanted characters.
- Press the **right selection** key to return to the **Setup Menu**.
- Press the **down arrow** key to highlight **CSD Settings** and press the **M** key.
- Press the **M** key to select **Phone No.** and leave it blank.
- Use the **right selection** key to delete any unwanted characters.
- Press the **down arrow** key to highlight **Line Type** and press the **M** key.
- Select **ISDN** and press the **M** key.
- Leave the **UserName** and **Password** blank.
- Press the **right selection** key to return to the **Setup Menu**.
- Press the **down arrow** key once to highlight **Setup End** and press the **M** key.
- Press the **M** key twice to activate the newly defined profile.