

# Sony Ericsson T100 Guide



## OTA Setup

- Please email [internet.support@vodafone.co.nz](mailto:internet.support@vodafone.co.nz) or call us on 977 from your mobile. Calls to 977 will be charged at your normal airtime rate for **OTA Setup**.
- Once the phone has received the settings, it will display **New settings received, Install?** Press **Yes**.
- Choose an available profile (generally **Profile 1**) which the settings will overwrite and rename **Vodafone**. Press **Yes** on the free profile.
- After this is done, follow 'Connecting to WAP' below.

## Complete Setup

- Scroll through the menu by pressing the left arrow key twice until you reach the **WAP Services** menu.
- Scroll down to **WAP Settings** and press **Yes**.
- Choose the next available profile (normally **Profile 1**) by pressing **Yes**.
- Choose **Rename** by pressing **Yes** and if necessary, clear the old name of the profile by pressing and holding the **C** key. Enter the name **Vodafone**, then **Yes**.
- Scroll down to **Chg Homepage** and select it by pressing **Yes**. If necessary, delete the old title by pressing and holding the **C** key and then enter the title of **Vodafone** and then press **Yes**.
- After completing the previous step, the homepage will appear for editing. If necessary, clear the old address by pressing and holding the **C** key. Next, enter the following address: **http://wap.vodafone.co.nz/** and press **Yes**.

Use the following table for entering in the symbols for the homepage:

:	1 seven times
.	1 six times
/	0 four times
?	1 three times
=	1 twelve times

- Scroll to **GSM Data** and press **Yes**.
- Scroll to **Phone Number** and press **Yes**. Enter **+6421700747** as the number, entering plus by holding down zero, then press **Yes**.
- Scroll to **Dial Type** and hit **Yes**. Scroll down to **ISDN** and select **Yes**.
- Scroll to **User ID** and hit **Yes**. Enter your user id as **voda** then press **Yes**.

- Scroll to **Password** and press **Yes**. Enter the password **fone** and press **Yes**. As you enter the password, it will appear as stars so watch the text bar at the top right of the screen to see which letter you are on.
- Press **No**, then scroll to **Gateway** and press **Yes**, then scroll to **IP Address**. Press **Yes**, then enter **172.030.038.003** and press **Yes**.
- Press **No** four times, then scroll up to the first heading on the menu (this should read **Vodafone**) and then press **Yes**. This will start the phone connecting to WAP.
- In the future, follow 'Connecting to WAP' below.

If **Vodafone** is not selected and another Profile is in its place (i.e. *Profile 2*) scroll down to **WAP Profile** and press **Yes**. Highlight **Vodafone** and press **Yes**, then follow the above step.

### **Connecting to WAP**

- Scroll left twice to **WAP Services**.
- Scroll down once and select **Vodafone** by pressing **Yes** (or whatever the homepage is called, i.e. **Profile 1**.) The phone will start connecting to the WAP gateway.

### **Overseas WAP**

- Scroll left twice to **WAP Services**.
- Scroll down to **WAP Settings**.
- Select **Vodafone** (or whatever their profile for WAP Connection is called) by pressing **Yes**.
- Scroll to **GSM Data** and press **Yes**.
- Scroll to **Dial Type** and select it by pressing **Yes**. Now change **ISDN** to **Analogue** by scrolling down to **Analogue** and pressing **Yes**.
- Press **No** four times to get back to the main WAP menu, then scroll up to **Vodafone** (or once again, whatever their selected profile is called) and press **Yes**.

### **Disconnecting from WAP**

- At any point while using the WAP service, simply press and hold the **No** key to disconnect.